





NOTES:

1. ITEM 97 IS SHOWN 90° OUT OF POSITION.
2. ITEM 98 USED WHEN REQUIRED.
3. SECURES YOKE TO MIXER HOUSING. ITEMS NOT SHOWN.



1	GEAR CARRIER ASSEMBLY
2	RING GEAR
5	PIN
7	RETAINING RING
27	KEY
35	QUILL
36	BEARING HOUSING MACH.
37	BALL BEARING
38	OIL SEAL
41	BALL BEARING
42	IMPELLER SHAFT
44	INTERNAL RETAINING RING
49	OIL SEAL
50	INTERNAL RETAINING RING
56	EXTERNAL RETAINING RING
82	NEEDLE VALVE
84	MUFFLER
96	HEX SOC SET SCREW
97	SQ HD PIPE PLUG
98	MOTOR SPACER RING
101	MOTOR
112	HEX HEAD CAP SCREW
113	HEX HEAD CAP SCREW
114	YOKE
115	BEAM PLATE
120	MOTOR COVER ASSEMBLY
121	WASHER
122	HEX NUT
123	ANTI-ROTATION INSERT
150	COUPLING
210	BUTTON HEAD CAP SCREW

ITEM	PART NAME
------	-----------

ALL EQUIPMENT DESIGN AND APPLICATION DATA SHOWN HEREIN AND RELATED KNOW-HOW ARE CONFIDENTIAL AND PROPRIETARY AND REMAIN THE PROPERTY OF SPX CORPORATION. NO USE OR DISCLOSURE THEREOF MAY BE MADE WITHOUT THE WRITTEN PERMISSION OF SPX CORPORATION.

SPX >Lightnin®

ASSEMBLY DRAWING

**NETTCO MODELS
MS5P & MS6P
GEAR DRIVE
AIR MOTOR**



COPYRIGHT © 2013 SPX CORPORATION

DRAWING NO. L-18535